Moen Faucet Cartridge Chart

Take the handle off and look at what holds the cartridge in.

CARTRIDGE	FAUCET	WHAT HOLDS IT	HANDLE TURN
1225	One handle (since 1981)	U-shaped copper clip	130 to 360 deg
4000 or 40002	One handle, kitchen	Brass hex nut	110 deg
Duralast 150257	Models 7170, 7597, S5170	Brass hex nut	100 to 110 deg
Duralast 160657	One handle (after 2009)	Black plastic nut, notches	100 to 110 deg
Duralast 1255	One handle (after 2009)	Black plastic hex nut	100 to 110 deg
210381	Kitchen, side handle (2022)	Brass nut, 2 flat areas	90 deg
202233 / 212555	Bath, one handle	Black plastic hex nut	100 deg
1269	Bath, one handle (2025)	Black plastic hex nut	100 deg
1224 / 1234	Two handles	Stem: white plastic / steel	90 or 180 deg
1248	Roman tub, deck mount	0.84 in across	180 deg
1258	Roman tub, deck, wall, floor	0.88 in across	90 deg

Turn the water off under the sink and open the faucet to relieve the pressure first.

Duralast kits 1255, 160657, 150257 and 205013 have different retainer nuts. Replace the nut with the kit. 205013: top handle pullout kitchen faucets after 2009.

202233 nut: component number 1000149. 212555 nut: 200485. Not interchangeable.

1224 and 1234 aren't interchangeable, nor are 1248 and 1258.

Moen one-handle shower: 1225 if the handle pulls out, 1222 (Posi-Temp) if it only turns; M-CORE 1212 or 1213.

Delta and Pfister: find the faucet's model, then its parts list.

Sources: Moen cartridge guides and instruction sheets, Delta part pages, Pfister FAQ.